

TYNETEC ZFT 210



Terminals

10V
0V
INTRUDER
IP2 / SCLK
IP1 / SDATA
C2
C1
STROBE –
ENABLE

IMPORTANT NOTE :

- 1) Before replacing the handset make note of the wires to each terminal on the existing unit (an easy way is to cut each core off leaving a piece of the insulation in place with colour visible) twist unused cores together (so you know they are not used, do not short them out).
- 2) Some older systems will have cable with one coloured core and a solid white core in this case mark each core with a marker or tape.
- 3) Some systems may have loop on wiring, you will have 2 cables into your handset (make sure any joins remain, as these may be serving other flats on the system).

QUICK GUIDE

LED	STATUS	OPTIONS
Not Lit	Normal Operating Mode	Lift handset when the telephone rings
Red	Privacy Mode On	Press pushbutton to turn Privacy Mode Off
Green	Door Open	Close the main entrance door to secure the building

NOTE

1. If the LED flashes alternate colours then both conditions exist
2. If the telephone beeps once a minute the door has been left open

www.intercomsrus.com



FM0582 ISSUE A

USER GUIDE

FOR YOUR

ENTEL 300 DOOR ENTRY TELEPHONE



www.intercomsrus.com


Tynetec Model No. ZFT210/ZFT211

INTRODUCTION

Your Entel 300 telephone is used to answer calls from visitors using the buildings door entry system. The pushbutton has two functions;

1. it can release the main entrance door and allow your visitors access
2. it can select privacy mode and prevent nuisance calls

The LED indicator may illuminate different colours to identify a number of conditions.



It is important that you read these instructions before use, if you need further assistance please contact your Housing Officer.

TO ANSWER A CALL

Your telephone will ring when a visitor is calling.
The ring tone will repeat for 40 seconds or until you pick-up the handset.
Lift the handset and speak with the caller.
To allow access, press the telephone pushbutton once.
You will hear beeps in the earpiece when the lock is released.
The LED indicator will illuminate green when the entrance door is opened.
Replace the handset on the hook to end the call.

Remember, if you do not want to let the caller in or you are unsure of their identity simply replace the handset to end the call.

If you hold a conversation to within 5 seconds of the preset speech time you will hear timeout pips before the call is automatically cancelled.

DOOR OPEN INDICATION

When the building entrance door is open the LED indicator will illuminate green on ALL telephones simultaneously - when the door is closed all will extinguish.

If the LED is illuminated green for an extended period it is likely that the entrance door has been left open and the building is not secure.

Note: if your system is configured with "Door Open Tones" then ALL telephones will beep once a minute until the door is closed.

TO SELECT PRIVACY MODE

You can select privacy mode if you do not want to receive any calls;

With the handset on-hook and the phone not ringing, press the pushbutton once. The LED indicator will illuminate red to indicate privacy is on. You cannot receive any calls when privacy is on.

To return to normal operation, press the button again and the red LED will go out.

Note: if your system is configured with "Timed Privacy" then the telephone will automatically revert to normal operation after a preset period.

FLASHING LED INDICATOR

If you have privacy mode selected and the main entrance door is opened the LED indicator will flash red/green until the door is closed.

ALTERNATIVE RING TONES

Your telephone has three user selectable ring tones;

With the handset on-hook and no call in progress, press and hold the pushbutton until the telephone starts to ring. Keep the button pressed to cycle through the ring tone options, release the button when your chosen tone is sounding.

www.intercomsrus.com