

ISM 2450/NIDT



Terminals

S
2
3
4
P1
C
P2
PO
SI
DM
+

IMPORTANT NOTE :

1) Before replacing the handset make note of the wires to each terminal on the existing unit (an easy way is to cut each core off leaving a piece of the insulation in place with colour visible) twist unused cores together (so you know they are not used, do not short them out).

2) Some older systems will have cable with one coloured core and a solid white core in this case mark each core with a marker or tape.

3) Some systems may have loop on wiring, you will have 2 cables into your handset (make sure any joins remain, as these may be serving other flats on the system).

HANDSET CONVERSION FOR 2600 TO 2450 TYPE HANDSETS:

1500 & 2650 SYSTEMS inc Concierge Systems

www.intercomsrus.com

	COLOUR	2450/NIDT NEW	2600/NIDT OLD	2600/NID OLD
V+	BROWN/WHITE	+	23	Orange in phone
2	BLUE/WHITE	2	19	2
3	WHITE/BLUE	3	20	3
CT	ORANGE/WHITE	SI	1	A
LK	WHITE/BROWN	P1	P1	P1
DM	WHITE/GREEN	DM	21	Red in phone
OV	GREEN/WHITE	PO	22	Green in phone
CC	SLATE/WHITE	P2	P2	P2

NOTE: THESE INSTRUCTIONS MUST ONLY BE USED WITH THE 2450 HANDSET

www.intercomsrus.com

SETTING PRIVACY TIME: (TOP LEFT OF BOARD; LINK 1 = '4', LINK 2 = '8')

LEAVE BOTH LINKS IN '4 & 8' FOR 12 HOURS PRIVACY.

www.intercomsrus.com

CUT LINK 1 '4' FOR 4 HOURS PRIVACY.

CUT LINK 2 '8' FOR 8 HOURS PRIVACY.

CUT BOTH LINKS '4 & 8' FOR PERMANENT 'OFF/ON'.

NOTE: 2450 HAS ORANGE AND YELLOW WIRES VISIBLE INSIDE HANDSET

www.intercomsrus.com

2450 Handset Conversion for Installation

CALLER ENTRY

1. When the buzzer sounds, lift the receiver and identify who the caller is.
2. If you wish to allow the caller access then press and release the 'KEY' button. This will unlock the main entrance door.
The red 'DOOR OPEN' lamp will light whilst the door is open.
3. Replace the receiver.

CONCIERGE CALL (if fitted)



1. To call the Concierge Office, press the button and release and await a call back.

HANDSET ON/OFF (Privacy)

www.intercomsrus.com

1. If you wish to turn the phone 'OFF' press and release the 'PRIVACY ON' button
The green lamp will light and the phone will now not ring.
2. To turn the phone back 'ON', press and release the 'PRIVACY ON' button.
The green lamp will turn off and the phone will now ring.
3. If the phone is left switched 'OFF' it will automatically reset to 'ON' after 4 to 12 hours.

www.intercomsrus.com

PLEASE NOTE THAT WHEN THE GREEN LIGHT IS ON THEN THE PHONE WILL NOT RING



www.intercomsrus.com