

# BPT AGATA C 200 UK



## Terminals (Conversion shown for older handset (AGATA C 200 & YC200 to old C-200))

AGATA C 200  
& YC 200

		C / 200
5	Common	1
9	Speech Out (Mic)	2
8	Speech In (Speaker)	3
7	Call	4

D 1,2 Aux Button (Volt Free)

### IMPORTANT NOTE :

1) Before replacing the handset make note of the wires to each terminal on the existing unit (an easy way is to cut each core off leaving a piece of the insulation in place with colour visible) twist unused cores together (so you know they are not used, do not short them out).


2) Some older systems will have cable with one coloured core and a solid white core in this case mark each core with a marker or tape.

3) Some systems may have loop on wiring, you will have 2 cables into your handset (make sure any joins remain, as these may be serving other flats on the system).

# WIRING DIAGRAM

## BPT 1 Way Audio

NOTE:  
THIS DRAWING INDICATES AND ASSUMES THE USE OF  
A MINIMUM OF 0.5MM CSA PER CORE.



# WIRING DIAGRAM

## BPT Audio with 2 Entrance Panels and Keypads

CALL LINES TO FURTHER YC/200'S.

COMMON LINES TO FURTHER YC/200'S.

NOTE:  
THIS DRAWING INDICATES AND ASSUMES THE USE OF  
A MINIMUM OF 0.5MM CSA PER CORE.

